






Product Information

Model No. PBB121



Slim Portable Power Banks

6,000 mAh Mobile Charging 2-Pack

Support

Thank you for your purchase!

We're committed to creating the most beautiful and high performance mobile charging accessories available. If you love getting charged up with Ubio, please write a review online.

If for any reason you are unhappy with your purchase, or require assistance, contact us so we can make it right.

DO NOT RETURN TO THE STORE

Our customer service team is here to help.

www.ubiolabs.com
support@ubiolabs.com
or 1-866-642-4428
(Monday-Friday, 9am-5pm PST)

Warranty



At Ubio Labs we are dedicated to designing and manufacturing products with superior performance and 100% customer satisfaction. All of our products come with a 1 year limited warranty from date of purchase.

6,000 mAh Power Bank

Charging The Power Bank

To charge the power bank, simply plug-in the included cable from the wall charger to the micro USB input.

When charging, LED lights display the battery charge level.




Charging A Device

The included cable is to charge the power bank. To charge your device, use a cable that is compatible with your phone or tablet.

Plug-in your mobile device to the 2.4A output, the power bank will automatically turn on and the LED lights will illuminate indicating your device is charging.


Once the device is fully charged, the power bank will automatically turn itself off.

The power bank is compatible with most phones, tablets, wearables and other devices that charge from a standard USB port.



LED Indicators

When the power bank is on, the LED lights display the remaining capacity of the power bank.



Important Safety Instructions

WARNING – When using this product, basic precautions should always be followed, including the following:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, supervision is necessary when the product is used near children.
- c) Do not put fingers or hands into the product.
- d) Do not expose power bank to moisture, rain or snow.
- e) Use of a power supply or charger not recommended or sold by power bank manufacturer may result in a risk of fire or injury to persons.
- f) Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- g) Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- h) Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- i) Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 150°F may cause explosion.
- j) Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.

SAVE THESE INSTRUCTIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.